

# Hako Sweepmaster 800R *Hako*

## Operation

1. Disconnect charger plug from outlet and place it to its box **1**.
2. Release the parking brake by pressing the brake pedal **2**.
3. Switch on the machine by key **3**.
4. Actuate drive direction from switch **4** and switch on the cylinder broom and the side brush from switch **5**. If necessary, lower the side brush by pushing lever **6** forward.
5. Press pedal **7**, machine moves.  
**NOTE!** Open the bypass flap **8** before sweeping wet surfaces and collecting wet dirt.



## Maintenance

- To clean the paper air filter, pull the shaking device lever **9** out and push back in again several times.
- If the filter is very dirty, lift the seat of the machine up at the back. Open the filter cover fasteners and remove the cover **10**. Remove and clean the filter **11** by dropping it evenly from a small height onto a level, solid surface a few times with the *dirty side down*.
- Remove and empty the dirt hoppers **12** by lifting the bar **13** up → the dirt hoppers are lowered down to disposal and empty.
- Charge battery



**Qualified persons only are authorised to operate the machine!**

Refer to the operating instructions for further details on proper use!  
You can find manual by reading QR-code.

